

CARE & MAINTENANCE

MetWall partition system does not need a recurring maintenance. Handles or knobs may need to be adjusted due to their continuous use. Neither high knowledge nor special tools are necessary to make this adjustment.

Framed glass closings should be considered. These closings are not sealed, so in installations with high environmental dust, the glass modules should be taken out regularly to clean the internal side of the modules. This action should be carried out by specialized staff following the usual assembly/disassembly procedure.

Cleaning of Laminate Panels

Laminate panels may be cleaned with a damp cloth, warm water and mild detergents.

Dilute a small quantity of detergent in water. Ammonia should be used only on stubborn stains. Apply the solution on the stain using a damp cotton cloth; do not rub too hard. Rinse it with clean water. Wipe the panel using a dry cotton cloth and avoid leaving stains.

Cleaning of Glass

Glass may be cleaned with a damp cloth, warm water and colorless products specific to glass.

Dilute a small quantity of ammonia or glass cleaner in water. Apply the solution on the glass surface using a damp cotton cloth. Wipe the glass surface.

Cleaning of Metallic Surfaces

Metallic surfaces may be cleaned with a damp cloth, warm water, and mild detergents.

Dilute a small quantity of detergent in water. Ammonia should be used only on stubborn stains. Apply the solution on the stain using a damp cotton cloth; do not rub too hard. Rinse it with clean water. Wipe the metallic surface using a dry cotton cloth and avoid leaving stains.

Do not use abrasive cleansers powders, scouring pads, steel wool, sandpaper, etc., they will scratch or damage the surface and are not recommended. Acid or alkaline-based cleaners, compounds, etc., will mar, etch, corrode, and permanently discolor the decorative surface of laminate.

Always test any new cleaner in an inconspicuous spot to ensure no degradation of the surface will occur.

For technical assistance, please contact us at info@metrikaoffice.com